

Revision A 2014-11-25

INSTRUCTION MANUAL

Original Instructions
Sliding Table Saw

**MODEL: N-1600E
N-2500E
N-3200E**

CE

Contents

- 1. Foreword**
- 2. Warranty Information**
- 3. Machine Description**
 - 3.1 Feature Identification**
 - 3.2 Intended Use**
 - 3.3 Dimensions and weights**
 - 3.4 Requirements of electrical power**
 - 3.5 Noise**
 - 3.5.1 Reference standards**
 - 3.5.2 Operating conditions**
 - 3.5.3 Testing results**
 - 3.6 Technical parameters**
- 4. Safety Regulations**
 - 4.1 General Safety Instructions**
 - 4.2 Specific Safety Instructions for Sliding Table Saw**
 - 4.3 Residual risks**
 - 4.4 Safety equipment**
 - 4.5 Safety labels on the machine**
 - 4.6 Safety devices**
- 5. Installation of the machine**
 - 5.1 Transportation of machines**
 - 5.1.1 Transportation and store**
 - 5.1.2 Transportation before unpacking**
 - 5.1.3 Confirmation after unpacking**
 - 5.1.4 Transportation after unpacking**
 - 5.2 Unpacking**
 - 5.3 Safety measures before use/installation**
 - 5.4 Installation**
 - 5.4.1 Moving & Placing Base Unit**
 - 5.4.2 Installation of Sliding Table**
 - 5.4.3 Installation of crosscut table**
 - 5.4.4 Side Extension Table Installation**
 - 5.4.5 Rear Extension Table Installation**
 - 5.4.6 Installation of Rip Fence Scale Tubing and Guide Bar**
 - 5.4.7 Blade installation and changing**
 - 5.4.8 Blade Guard & Riving knife installation**
 - 5.4.9 Connecting the extraction system**
 - 5.4.10 Electrical installation**
- 6. Adjustment**
 - 6.1 Sliding table**
 - 6.2 Main Table**
 - 6.3 Scoring blade**
 - 6.4 90 and 45 degree stops**
 - 6.5 Crosscut fence**
 - 6.6 Rip Fence**
- 7. Operations**
 - 7.1 Safety Cautions**
 - 7.2 Electrical Operations**
 - 7.3 Digital Readout of fence angle Operation**

7.4	Digital Readout of blade angle Operation
7.5	Blade Guard/Riving knife
7.6	Crosscutting
7.7	Rip cutting
7.8	Clamping shoe
8.	Maintenance
8.1	Cleaning
8.2	Lubrication
8.3	Replacing belt
9	Trouble shooting guide
10	Parts list

1. Foreword

This manual contains basic information for qualified operating staff and describes the surroundings and using ways of the machine for those it is intended. It contains also all necessary information for a correct and safe operating, the machine is equipped with various safety equipment protecting operator and machines well at usual technological using. These regulations, however, cannot sheet all other safety aspects. That is why operator must peruse and make sense of this manual before starting of machine use. Installation and operation mistakes will be foreclosed herewith.

Do not try to start the machine before having read all instructions manual delivered with the machine and understood every function and technique.

2. Warranty Information

Limited Warranty

One year

Proof of Purchase

Please keep your dated proof of purchase for warranty and servicing purposes.

Limited Tool Warranty

We makes every effort to ensure that this product meets high quality and durability standards. we warrants to the original retail consumer a 1-year limited warranty as of the date the product was purchased at retail and that each product is free from defects in materials. Warranty does not apply to defects due directly or indirectly to misuse, abuse, normal wear and tear, negligence or accidents, repairs done by an unauthorized service center, alterations and lack of maintenance. we shall in no event be liable for death, injuries to persons or property or for incidental, special or consequential damages arising from the use of our products.

To take advantage of this limited warranty, return the product at your expense together with your dated proof of purchase to us ,we will either repair or replace the product if any part or parts covered under this warranty which examination proves to be defective in workmanship or material during the warranty period.

3. Machine Description

3.1 Feature Identification




Fig.1

No.	Description	N1600	N2500	Remark
1	Main Base Unit	●	●	
2	Swing Arm	●	●	
3	Crosscut Table	●	●	
4	Crosscut Fence	●	●	
5	Sliding Table	●(1600mm)	●(2500mm)	
6	Edge Shoe Plate	●	●	
7	Rear Extension Table	●	●	
8	Blade Guard With Riving Knife	●	●	
9	Main Table	●	●	
10	Side Extension Table	●	●	
11	Round Guide Bar)	●	●	
12	Rip Fence Body	●	●	
13	Rip Fence	●	●	
14	Support Leg for Extension Table	● (3pcs)	● (3pcs)	
15	Support Leg for Sliding Table	/	● (2pcs)	

3.2 Intended Use

The sliding table saw and the workpiece guide equipment supplied with it are intended to be used exclusively for the following purposes:

- Laminated and unlaminated board materials (e.g. chipboard, coreboard, MDF board, ...)
- Solid wood
- Gypsum plasterboard , Cardboard, Veneer with a suitable clamping device
- Dimensionally stable plastics (thermoset plastics, thermoplastics).Sawing these materials does not normally involve any risks in respect of dust, chips, and thermal degradation products.

Tools:

- The chosen saw blade must be suitable both for the specific work cycle and for the specific material.
- Only circular blades which are solid chrome vanadium (CV) or tungsten carbide tipped (TCT) and have a diameter of 315mm , arbor size 30mm,as well as a maximum width of 20mm are allowed for the main saw
- Blades with a diameter of 120mm,arbor size 20mm are allowed for the scoring saw.
- Saw blades made of high-alloy high-speed steel (HSS) are not allowed to be used.
- Saw blades and their fixing devices shall conform to EN 847-1:2005.

Site of installation/use:

- The machine is not suitable for use outdoors, or in rooms that are subject to moisture or the risk of explosions.
- The intended use of the machine involves connection to a suitably dimensioned extraction system .
- Intended use also involves compliance with our specified operating, maintenance and repair conditions and the safety information contained in the operating instructions.
- The sliding table saw may only be used, set up and maintained by persons who are familiar with the machine and aware of the dangers.
- The pertinent accident prevention regulations as well as any other generally recognised technical safety and industrial medicine rules must be observed.
- Repair work must be carried out by our own customer service or by an organization that we have authorized. Only original spare parts are allowed to be used for this. we will assume no warranty for any damage that is caused by using non-original spare parts.

Machine operator positions(Fig.2)

The sliding table is intended to be operated from the following positions:

- On the left of the sliding table at the front of the machine, seen in the feed direction (main operator position).
- At the front cross-end of the machine on the right of the sliding table when working with the rip fence
- Any person removing the workpieces must stand at the rear cross-end of the machine behind the main table length extension (under no circumstances in the sliding table traverse area).




Fig.2

 **WARNING**

The machine is prohibited to be used in a potentially explosive atmosphere!

3.3 Dimensions and weights

Machine Type	Packing	Net/Gross weight	Dimensions of box
		(Kg)	(DxWxH)mm
N-1600	machine box	480/550	1650x1150x1090
	sliding table box	40/70	1860x360x220
	Crosscutting fence box	15/25	2000X320X170
N-2500	machine box	505/575	1650x1150x1090
	sliding table box	60/107	1860x360x220
	Crosscutting fence box	15/25	2000X320X170
N-3200	machine box		
	sliding table box		
	Crosscutting fence box		

3.4 Requirements of electrical power

List of the motor using & pre-wired voltage

Main Motor/scoring motor(KW)	Voltage(V)	Freq.(Hz)	Nominal current A with scoring blade	Prewired	Cords
4(S-6)/0.55	380V-420V	50(60)HZ	6.57/1.4	400V 3PH	5
4(S-6)/0.55	200V-240V	50(60)HZ	12.8/2.5	220V 1PH	3

The input power supply of the machine is 3/N/PE, AC400V. The steady-state AC power supply is 0.9~1.1 times of the rated value.

- **Frequency**

0.99~1.01 times of rated frequency (50 Hz , continuous working)

0.98~1.02 times of rated frequency(50Hz, short period working)

- **Harmonics**

The sum of 2nd-5th distorted harmonic must not exceed 10% of RMS of voltage. An additional 2% of RMS of line voltage is allowed to for the sum of 6th-30th harmonic.

- **Unbalanced voltage**

Neither Negative nor zero sequence components is allowed to exceed 2% of the positive sequence component.

- **Electrical protection**

End user should provide protection device against overvoltage due to lightning and short-circuited protection device at the power supply.

- **Ingress Protection at the inlet of incoming power cable**

The incoming method of incoming cable should ensure IP54 protection class when finishing installation on the spot.

3.5 Noise

3.5.1 Reference standards

The measurements of noise emission were conducted according to the EN ISO 11202 for the determination of sound pressure level at the operation positions. When the measured sound pressure levels at the operation positions exceed 85dB(A), the measurements of sound power levels were conducted according to EN ISO 3746.

3.5.2 Operating conditions

The operating conditions for noise measurement comply with Annex A of ISO 7960:1995.

3.5.3 Testing results

		NO LOAD	LOAD
L_{WA}		91.8	97
L_{PA}	Position A	77.7	85.0
	Position B	80.3	86.5
	Position C	73.0	74.9
Associated uncertainty		<i>K</i> = 4 dB	

Note: Background noise of measurement surrounding is 65.0dB (A).

The figures quoted are emission levels and are not necessarily safe working levels. Whilst there is a correlation between the emission and exposure levels, this cannot be used reliably to determine whether or not further precautions are required. Factors that influence the actual level of exposure of the workforce include the characteristics of the work room, the other sources of noise etc. i.e. the number of machines and other adjacent processes. Also the permissible exposure level can vary from country to country. This information, however, will enable the user of the machine to make a better evaluation of the hazard and risk.”

3.6 Technical parameters

Models		N-1600	N-2500	N-3200
Overall Dimensions	Overall Size (DxWxH)mm	3680X4680X1050	5480X4680X1050	6880X4680X1050
	Table Height(mm)	860		
	main Table Size(mm)	495X860		
	Sliding Table Size(mm)	310X1600	310X2500	310X3200
	Machine Net Weight	Approx. 645KG	Approx.700KG	Approx.780KG
	Machine foot print	870X1300		
Capacities	Main Blade Diameter (Maximum)	315mm		
	Main Blade Arbor Size	30mm		
	Main Blade Arbor Speed	4500/min		
	Scoring Blade Diameter	120mm		
	Scoring Blade Arbor Diameter	20mm		
	Scoring Blade Arbor Speed	8000/min		
	Maximum Depth of Cut at 90°	105mm		
	Maximum Depth of Cut at 45°	76mm		
	Dado Width (Maximum)	15mm		
	Blade Tilt	Right		
	Maximum Ripping Capacity	1270mm		
	Maximum Length of Cross Cut Fence	2850mm		
	Maximum Cross Cutting Length	1500mm	2400mm	3100mm
Construction	Sliding Table	T-6 Heavy Duty Extrusion		
	Machine Frame	High Strength Steel Welding (Laser Cut)		
	Cross Fence	Extruded T-6 Aluminum with fine anodization		
	Rip Rails	40mm Round bar guide		
	control & read-out	Electric Control, Angle digital display		
	Trunnion	High Grade Cast Iron, Precisely Machined		
Motor	400V/50(60)Hz/3Ph/3Kw 2850 (3450) /min TEFC			
Power Transfer	Belt Drive			
Features	Electronic angle adjustment with digital read-out			
	Electronic height adjustment			
	100mm Main Dust Port			
	Adjustable Riving Knife			
	Ball Bearings: Sealed and Permanent Lubrication			

Every machine we produce is fitted with a name plate with its serial number. The number is also punched on the machine.

An exact description of the machine model and serial number will facilitate rapid and effective replies from our after-sales service.

Position of nameplate: on the side of the main base unit.

WARNING

It is prohibited to alter the information given on the nameplate!

4. Safety Regulations

4.1 General Safety Instructions

1. KNOW YOUR MACHINE.

Read and understand the owners manual and labels affixed to the machine. Learn its application and limitations as well as its specific potential hazards;

2.GROUND THE MACHINE.

In the event of the electrical short, grounding reduces the risk of electrical short;

3. KEEP GUARDS IN PLACE.

Keep in good working order, properly adjusted and aligned;

4. REMOVE ADJUSTING KEYS AND WRENCHES.

Form habit of checking to see that keys and adjusting wrenches are removed from machine before turning it on;

5. KEEP WORK AREA CLEAN.

Cluttered areas and benches invite accidents. Make sure the floor is clean and not slippery due to wax and sawdust build-up;

6. AVOID DANGEROUS ENVIRONMENT.

Don't use machines in damp or wet locations or expose them to rain. Keep work area well lit and provide adequate surrounding work space;

7. KEEPCHILDREN AWAY.

All visitors should be kept a safe distance from work area;

8. MAKE WORKSHOP CHILD-PROOF.

With padlocks, master switches or by removing starter keys;

9. USE PROPER SPEED.

A machine will do a better and safer job when operated at the proper speed;

10. USE RIGHT MACHINE.

Don't force the machine or the attachment to do a job for which it was not designed;

11. WEAR PROPER APPAREL.

Do not wear loose clothing, gloves, neckties or jewelry (rings, watch) because they could get caught in moving parts. Non-slip footwear is recommended. Wear protective hair covering to contain long hair. Roll up long sleeves above the elbows;

12. DON'T OVER REACH.

Keep proper footing and balance at all times;

13. MAINTAIN MACHINE WITH CARE.

Keep tools sharp and clean for best and safest performance. Follow instructions for lubricating and changing accessories;

14. DISCONNECT MACHINES.

Before servicing, when changing accessories or attachments;

15. AVOID ACCIDENTAL STARTING.

Make sure the switch is in the "OFF" 'position before plugging in;

16. USE RECOMMENDED ACCESSORIES.

Consult the manual for recommended accessories. Follow the instructions that accompany the accessories. The use of improper accessories may cause hazards;

17. NEVER STAND ON MACHINE.

Serious injury could occur if the machine tips over .Do not store materials such that it is necessary to stand on the machine to reach them;

18. CHECK DAMAGED PARTS.

Before further use of the machine, a guard or other parts that are damaged should be

carefully checked to ensure that they will operate properly and perform their intended function. Check for alignment of moving parts, breakage of parts, mounting, and any other conditions that may affect its operation. A guard or other parts that are damaged should be properly repaired or replaced;

19. NEVER LEAVE MACHINE RUNNING UNATTENDED.

Turn power "OFF". Don't leave any machine running until it comes to a complete stop;

20. LIGHTING SHALL BE PROVIDED.

A dequate general or localised lighting shall be provided;

4.2 Specific Safety Instructions for Sliding Table Saw

1. ALWAYS USE A GUARD.

Always use a guard, splitter and anti-kickback fingers on all "thru-sawing" operations. Thru-sawing operations are those when the blade cuts completely through the work piece as in ripping or crosscutting.;

2. ALWAYS HOLD THE WORK.

Always hold the work firmly against the miter gauge or fence;

3. ALWAYS USE A PUSHSTICK OR PUSH BLOCKS.

Push blocks or push sticks shall be used when cutting small workpieces and in circumstances where it is necessary to push the workpiece against the fence;

4. NEVER.

Never perform any operations "free-hand" which means using your hands to support or guide the work piece. Always use either the fence or the miter gauge to position and guide the work piece;

5. NEVER.

Never stand or have any part of your body in line with the path of the saw blade;

6. NEVER REACH BEHIND.

Never reach behind or over the cutting tool with either hand for any reason;

7. MOVE THE RIP FENCE.

Move the rip fence out of the way when crosscutting;

8. DIRECTION OF FEED.

Feed work into the blade against the direction of rotation;

9. NEVER.

Never use the fence as a cut-off gauge when you are cross-cutting;

10. NEVER.

Never attempt to free a stalled saw blade without first turning the saw OFF;

11. PROVIDE ADEQUATE SUPPORT.

To the rear and sides of the table saw for wide or long work pieces;

12. AVOID KICKBACKS.

Avoid kickbacks (work thrown back towards you) by keeping the blade sharp, by keeping the rip fence parallel to the saw blade, by keeping the splitter and anti-kickback fingers and guard in place and operating, by not releasing work before it is pushed all the way past the saw blade, and by not ripping work that is twisted or warped or does not have a straight edge to guide along the fence;

13. AVOID AWKWARD OPERATIONS.

Avoid awkward operations and hand positions where a sudden slip could cause your hand to move into the spinning blade;

14. BLADE REQUIREMENTS.

Only correctly sharpened saw blades manufactured in accordance with the requirements of EN 847-1:2005 shall be used;

15. SPEED.

No saw blade shall be used where the maximum marked speed is lower than the maximum rotational speed of the saw spindle;

16. CHIP AND DUST.

The machine shall be connected to an external chip and dust extraction system;

The dust extraction equipment is to be switched on before commencing machining;

17. CHECK

Period check the brake function to make sure the stop time of the saw blade is less than 10s;

4.3 Residual risks

1. Take precautions to reduce the hazard of inhalation of harmful dusts (e.g. wearing a dust mask);
2. Wear ear protection to prevent hearing loss;
3. Always wear safety glasses. also use a face or dust mask if cutting operation is dusty;
4. Against the hazard of cutting when handling saw blades into the machine or doing maintenance;
5. Not to try removing chips whilst the saw blade(s) is (are) running and the saw unit(s) is (are) not in the rest position;
6. Not to try using the machine unless all of the guards and other safety devices necessary for machining are in good working order;

4.4 Safety equipment

A push block (*Fig.3*) and A push stick (*Fig.3*) must be used




Fig.3




Fig.4

WARNING

If the workpieces is less then 120mm,you must use the push stick to prevent your hands from getting too close to the saw blade.

Push block must be used to cut narrow workpieces and, when necessary, to push the workpiece against the fence, a push block can be easily made by the operator as Fig.3.

4.5 Safety labels on the machine

Here below you will find the warning labels that are attached to the machine and illustrated in the instruction, see **Fig.5**

- ①. Warning for residual risks And always use a push stick or push blocks.
- ②. Specific Safety Instructions for Sliding Table Saw.
- ③. Caution! Live equipment.
All electrical operation and maintenance shall be done by qualified electricians!
All electrical operation must be carried out in according to electrical instruction.
- ④. Warning for fence using.
- ⑤. Warning for motor cover open.




Fig.5




Fig.6

4.6 Safety Devices

Disconnect switch

Interval: 8hours

Position: As Fig.6

Operation: With an handle;

Emergent stop buttons

Interval: 8hours

Position: 2 emergency stop buttons are separately setting, as Fig.6

Operation: Press the emergent stop buttons when emergency.

Release the tripped person in the work zone by the emergent stop button in work zone.

Interlocking switches

Interval: 8hours

Position: As Fig.6

Interlocking switch-A: when open the cover, the motor power will be off.

Interlocking switch-B: when the scoring is under the surface of the table, the motor power will be off.

Followed in the event of accident or breakdown, you must press the Emergent stop buttons, and handle the disconnect switch to cut the power.

When you setting up, operation, service the machine, you must pay increased attention to avoid the potential dangers.

Every time, before you operation the machine, you must check the **Disconnect switch, Emergent stop buttons, Interlocking switches** if in order.

 **NOTICE**

Emergency stop buttons are prohibited to act as normal stop function.

5. Installation of the machine

5.1 Transportation of machines

5.1.1 Transportation and store

The measures of anti-rust and shockproof should be taken during packing. The machine endures transportation and store in -25~55°C ambient temperature. Be care of not making machine exposed to rain or damaging the packing during transportation and store.

WARNING

- While transporting or handling the machine, be careful and let the activity be done by qualified personnel especially trained for this kind of activity!
- While the machine is being loaded or unloaded, make sure that no person or subject gets pressed by the machine!
- Select proper transportation device according to the weight of the machine.
- Make sure the lifting capacity of transportation device is competent for the weight of the machine.

5.1.2 Transportation before unpacking

As standard, the machine is packed in a robust wooden box. *Fig.7* shows the method can be used to transport the packing box.



Fig.7

5.1.3 Confirmation after unpacking

When open the packing box, please pay attention to the following stems. If you have any questions, please contact directly with us.

- 1) the machine is damaged in transportation or not
- 2) other accessories and documents is complete or not
- 3) the product is consistent with the contract or not
- 4) the specifications on machine label is consistent with the contract or not

5.1.4 Transportation after unpacking

When transport the machine with a stacker truck, firstly find the centre of gravity of the machine, insert the fork to the bottom of the machine and then rise or fall slightly.

5.2 Unpacking

your machine was carefully packaged for safe transportation. remove the packaging materials from around your machine and inspect it. if you discover the machine is damaged, please immediately call Customer Service for advice.

save the containers and all packing materials for possible inspection by the carrier or its agent. Otherwise, filing a freight claim can be difficult.

When you are completely satisfied with the condition of your shipment, inventory the contents.

Inventory

The following is a description of the main components shipped each J-20/J-30 model. lay the components out to inventory them.

Note: If you can't find an item on this list, check the mounting location on the machine or examine The packaging materials carefully. Occasionally we pre-install certain components for shipping purposes.

----Machine Box Contents: (Fig.8)




Fig.8

Machine Box Content:	Qty
A. Main unit	1
B. Blade guard and Riving Knife	1
C. Crosscut table	1
D. Rear extension table	1
E. Scale	1
F. Round guide bar	1

Machine Box Content:	Qty
G. Rip fence	1
H. Rip fence body	1
I. Side extension table	1
J. Clamping shoe	1
K. Motor cover	1
L. Support leg (for N-2500)	2

----Sliding Table Box Contents: (Fig.9)




Fig.9

Sliding Table Box Content:	Qty
A1. Sliding table Assembly	1
B1. Assistant support	1

----Cross-cutting fence Box Content: (Fig.10)

Sliding Table Box Content:	Qty
A2. Cross-cutting fence	1
B2. Stop plate	2




Fig.10

5.3 Safety measure before use/installation

Foundation plan (Fig.11)




Fig.11

Space Requirements (Fig.12)





Fig.12

5.4 Installation

5.4.1 Moving & Placing Base Unit



This model is a heavy machine, Serious personal injury will be happen if safe moving methods are no followed! To be safe, you will need assistance and power equipment when moving the shipping crate and removing the machine from the crate!

WARNING

Do not connect machine to electricity before installation is completed!

a, Main base is mounted at wood stock with three bolts at point A, B, C ,as(**Fig.13**), take out the bolts, separate the main base from wood stock, at the same time, raise bolts D .

b, Moving the main base to suitable place.

Space required: Refer to **Fig.12**, insure the inter space between the machine and wall at least 800mm.

ground required: There is no special ground required, the floor must have a load bearing strength for the machine weight and should be flat and level.

c, When main base is placed, adjust bolts D to make the machine level off. Then tighten D.




Fig.13

5.4.2 Installation of Sliding Table

Sliding table is packed separately from the main machine. So you need to install sliding table when cabinet is leveled.

WARNING

Always find the matching sliding table for the main machine!

The matching number is the Serial Number that are marked on main machine and sliding table as well as their packing boxes. Make sure the serial numbers on main machine and sliding table are the SAME. Otherwise will cause difficulties in assembling!

a, The sliding table is very heavy, you must moving it as **Fig.14**.

b, Fit the sliding table to main base, Push the sliding table all the way, make the block A against bolt B. as **Fig.16**, secure the sliding table with cabinet with M12 bolt C firmly, as **Fig.15**.




Fig.14




Fig.15




Fig.16




Fig.17

c. Insert the 4pin connector D to the socket of the main base, as **Fig.17**;

d, If your Sliding Table length is 2500mm, we provide two support legs, install the legs as **Fig.17**

e If you cut the irregular wood, you can use edge shoe plate, Slide the plate to the T slot of the sliding table.

5.4.3 Installation of crosscut table

a. Slide crosscut table into T slot of sliding table.

b. Align the screw shaft (B) of swing arm to the hole on the bottom of crosscut table (**Fig. 18**), and adjust the screw C & D, keep the surface of the crosscut table is parallel to the surface of the sliding table, then tighten the screw C & D. Lock the crosscut table with handle A, see **Fig. 18**.




Fig.18




Fig.19-1




Fig.19-2



c, The outrigger table system with swing arm will be in working position, install the crosscut fence onto the crosscut table with two positioning holes (**Fig.18**). Lock the fence onto the crosscut table with the knob (J) & (E), release knob (E), you can swing the fence, and can be locked in any degree (± 45 degree) with lock knobs (E), see **Fig.19-1**.

d, knobs (F) can be used to quick lock the fence for 90 degree, see **Fig.19-2**.

There is a lock block (G) at the bottom of the fence, turn the knob (F), you can quick lock or release the fence, release nut (I), turn screw (H) in or out, you can adjust the fence position.



5.4.4 Side Extension Table Installation

- a. Fix the side extension table to the side of the main table with three bolts (A), as **Fig.20**.
- b. Fit the legs (B) to the bracket of side extension table with bolts (C), as **Fig.20**.
- c. Adjust feet (D), ensure the side extension table is flat with the main table, as **Fig.21**, when adjustment is over, tighten the nuts of the feet(D).
- d. at the same time, ensure the Side of Extension Table is flat with the side of main table, as **Fig.22**, it is very importance for the installation of Rip Fence.



5.4.5 Rear Extension Table Installation

- a. Fix the rear extension table to the rear side of the main table with three bolts(A), as **Fig.23**.
- b. Fit the leg (B) to the bracket of Rear Extension Table with bolts (C), as **Fig.23**.
- c. Adjust feet (D), ensure the rear Extension Table is flat with the main table, as **Fig.24**, when adjustment is over, tighten the nuts of the feet(D).



5.4.6 Rip fence installation

1, Mount the scale bar to the main table and right extension table, making sure it is lower than the top of the table. **Fig.25**





Fig.25

Fig.26

2, Insert the guide round bar into the tables as shown in **Fig.26** Do not tighten the nuts at this time.
3, Slide the rip fence body onto the guide rail. (Note: Please remove the end cap firstly) See **Fig.27**.




Fig.27

4, Slide the aluminum rip fence onto the clamping plate and lock it with the lock handle See **Fig.27**.

5.4.7 Blade installation and changing

WARNING

Turn the power switch “OFF” and unplug the power cord from its power source when changing the saw blade.

When replacing blades, check the thickness stamped onto the riving knife. You must select a blade with a kerf width larger than the thickness of the riving knife. Thinner blades may cause the workpiece to bind during cutting.

Main blade installation and changing (Fig.28)

- Push sliding table all the way to the Right.
- Open blade cover
- Raise the spindle to the highest position
- Insert the locking pin (A) into the hole in the main table to hold spindle from rotating.
- Put blade onto spindle arbor and put on the clamping flange and locking nut. Use the wrench(comes with machine) to tighten the blade locking nut.
- Push back the blade cover

Use reverse steps to change blade.

Take out the lock pin after blade is installed.

Machine will not run when blade cover is not closed.




Fig.28

Scoring blade installation and changing (Fig.29)

- Push sliding table all the way to the Right.
- Open blade cover
- Use wrench(comes with machine) as shown to lock the scoring blade to arbor.
- Push back the blade cover

Use reverse steps to change blade.




Fig.29

NOTICE

Take out the lock pin (A) after blade is installed.


Machine will not run when blade cover is not closed.

5.4.8 Blade Guard & Riving knife installation

Installation of Blade Guard is the same as Installation of Riving knife

The Blade Guard & Riving knife can be adjusted in both horizontal and vertical directions, block(A) can be adjust left or right, the blade guard (B) can be adjust up or down. As **Fig.30**

Fig.30



After changing a saw blade, always check that the Riving knife or Blade Guard is correctly set!

1. riving knives shall be manufactured from steel with an ultimate tensile strength of 580 N

mm-2 or of a comparable material, have flat sides (within 0,1 mm per 100 mm) and shall have a thickness less than the width of cut (kerf) and at least 0,2mm greater than the saw blade plate. As

Fig.31

Key:

- e** riving knife thickness
- b** saw blade blade
- B** kerf (width of saw blade cut)




Fig.31

2, The distance of the riving knife from the gear rim must be between 3mm and 8mm. measured radially through the centre of the saw spindle. As **Fig.32**




Fig.32

3. the highest point of the riving knife must be set beneath the topmost teeth.

WARNING

Check that saw blade clamping system is tight before operating the machine.

5.4.9 Connecting the extraction system

NOTICE

Dust collector device should be prepared by customer;

WARNING

The dust extraction equipment is to be switched on before commencing machining;

As **Fig.33**

The outlet diameter of **A** is 100mm

The outlet diameter of **B** is 50mm

Air current speed is 20m/s for vacuum suction dust emission index, When air current speed of dust collector device (in accordance with EN 12779:2004) is not lower than 20m/s, ensure machine can be normal exhausted. User must wear dustproof mask.

Fig.33

1. Required air flow: 1500 m³/h;
2. Ensure pressure drop of each dust collector outlet carrying air current speed: 1100Pa
3. Wind speed of dust collector tube m/s: dry chips: 20m/s, water content is equal to 18% wet chips: 28m/s.




Fig.33

5.4.10 Electrical installation

WARNING

1. *Wiring should only be done by professional electricians.*
2. *All wirings in the cabinets should be protected against direct contact to at least IP2X when finishing electrical installation.*
3. *All exposed conductive parts should be connected to the protective bonding circuit.*
4. *Close and lock the door of cabinets, take off the keys and keep them well after finishing installation.*

NOTICE

1. *Enough space around the machine and the cabinets should be kept in order to maintain conveniently.*
2. *The machine should be installed in a workshop with good illumination and ventilation.*
3. *Over-voltage protection device should be provided by end user on spot.*

WARNING

Entrust this operation to qualified personnel. Always make sure the machine is properly earthed.

Check that the voltage and frequency required by the machine, shown on the machine's name plate, correspond to the electric power supply voltage and frequency.

The circuit breaker (16A) with RCD module (30mA) shall be installed for supplying electric power to this table saw, in order to protect people against electrical shock due to indirect shock

Wiring:

Finish electrical connection according to the electrical drawings.

The wirings on the spot should refer to the requirements of Clause 13 (Wiring practices) of EN 60204-1:2006.

Checking:

After finishing wiring on the spot, check the following items at least:

Check the wirings of machine.

Check the direction of motors and change wiring if necessary.

Check the components for defects, such as loosening or damage.

Check the functions of safety devices (such as interlocked guards and emergent stop buttons).

Check the direction of motors and change the phases if necessary.


Check the functions of all limited switches.

The terminals are marked L1,L2,L3,N,PE,

If blade direction is wrong, please change any two "L" terminal position.

ELECTRICAL CONNECTIONS

400V/50(60)Hz/3PH



No.	Code	Name	Specification
1	Q3	main switch+handle+bar	OT25F3, Uimp=8kv, Ith=32A, 50/60HZ +OHYBS1AH1(black-red) +OXS6X160
2	FU2,FU3	Fuse block	UK5-HES1,230V/400V, 2A
3	SE1	Safety limit switch	CNTD CZ-93B,3A/240V
4	T1	Isolation transformer	JCY5-63, AC220V-AC24V,63VA,50/60HZ,IP2X
5	ES1,ES2	E-stop button	CE3T-10R-02, 2NC,Ui=300V,Ith=5A
6	eb1	Thermal relay	NR2-25,9-13A
7	eb2	Thermal relay	NR2-25,1.6-2.5A
8	SU1,SU2,SU3	Stop button	CP1-10R-01,ABB
9	SA1	Selection switch	C2SS2-10B-10, 300V,5A
10	Height-M,Angle-M	Direct push rod	TA2-Sries,Power: DC24V,Duty cycle: 10%max2min/18min max load: push 2000N, Max current: Max 5.0Amp
11	SB1,SB2,SB3,SB4	Start button	CP1-10W-10, 300V,5A,1NO
12	KM1	Contactora	CJX2-3210
13	KM2,KM3	Contactora	CJX2-0910
14	SE2	Position switch	QKS7, AC15, 250V/10A
15	SC1,SC2,SC3,SC4	Control button	CP1-10G-20, 300V,5A,2NO
16	KA1,KA2,KA3,KA4	Contactora	CR-P024AC2+CR-PSS+CR-P/M+42-CR-PH
17	KT1,KT2	Time relay	H3YN-2
18	SQ1,SQ2,SQ3,SQ4	Position switch	QKS7, AC15, 250V/10A
19	M	Brake circuit board	102303002

6. Adjustment



NOTICE

Before operation, the machine should be carefully adjusted for best performance. Please make adjustment as following:

6.1 Sliding table

The sliding table must be parallel to the main blade.

- 1, Move the blade tilt to 0° (blade 90° to table), and raise the main blade as high as it will go.
- 2, slide the sliding table and use a dial indicator to Measure the parallelism, **Fig.34**
- 3, If no more than 0.1mm, the parallelism is correct. If not, continue with the next step




Fig.34




Fig.35

Note: A dial indicator may be used for this measurement

- 4, Loosen secure nuts under sliding table completely and hand tighten them.
- 5, Loosen nuts B, see **Fig.35**.
- 6, Turn thread rod C out or in.
- 7, Push sliding table all the way in order to ensure the block A is against the thread rod C.
- 8, Repeat step 2 and 3, till the parallelism is correct;
- 9, tighten screw B and the secure nuts of the sliding table.

6.2 Main Table

Main table should be about 0.1mm lower than sliding table.

- 1, Using a straightedge and feeler gauge to check if the main table need to be adjusted. If yes, continue next step.
- 2, There are four bolts support the main table on four cabinet corners. Loosen A and B and turn bolt C for height adjustment **Fig.36**
- 3, Repeat step 1
- 4, Secure A and B




Fig.36

6.3 Scoring blade

1. Adjusting knob (A) through the cabinet, right revolve, scoring blade up, left revolve, scoring blade down, as **Fig.37**.
2. Hex wrench (B), right revolve, scoring blade go forward, left revolve, scoring blade fall back, as **Fig.38**.




Fig.37




Fig.38

6.4 90 and 45 degree stops

1. Adjusting screw (A), you can change the electronic stop position at 45 degree, as **Fig.39**.
Adjusting screw (B), you can change the electronic stop position at 90 degree, as **Fig.40**.
2. Adjusting screw (C), you can change the fixed stop position at 45 degree, as **Fig.41**.
Adjusting screw (D), you can change the fixed stop position at 90 degree, as **Fig.42**.




Fig.39




Fig.40




Fig.41




Fig.42

6.5 Crosscut fence

Square to main blade:

1, The crosscut fence/miter fence must be set 90 degree to the blade. Take a 1000x1000mm MDF or similar material with thickness at least 15mm, Make 5 cuts. (Put the last cut side against the fence for the next cut, keep turn the test piece in same direction). Measure the 5th cut off strip at both ends. The difference will be less than 0.75mm, see **Fig.43**




Fig.43

Adjust as follow:

- 2, Loosen knob D, E, and nut A
- 3, Turn screw B in or out
- 4, Push the fence and make block C is against screw B. Tighten A.
- 5, Secure the fence to the cross-cut table
- 6, Repeat step 1.

Step 2-5 as **Fig.44**




Fig.44




Fig.45

Crosscut fence scale adjustment:

For the first time to use the fence or replacing blade, the scale must be re-adjust:

Set the stop plate (H) (**Fig.45**) at a certain location and cut a piece of workpiece.

a. measure the length of the workpiece, release the little knob (I) (**Fig.45**) under the fence, adjust the location of the scale to fit the length you measured, confirm the scale's location and lock the scale with knob (I)。

b. use the same mode to adjust the inner scale.

6.6 Rip Fence

NOTICE

Rip fence must be adjusted as next before you use it.

- a. To adjust the fence upright with the table surface, as *Fig.46*.
- b. To adjust the fence parallel with the blade.

the difference between L1 and L2 is 0.05-0.15mm, and that $L1 > L2$, as *Fig.47*




Fig.46




Fig.47

If the fence is not parallel with the blade, you can release the lock nut A (*Fig.48*), adjust the position of the round guide bar




Fig. 48




Fig. 49

- c. **Adjust the Rip fence scale:**

First time use or each time the blade change, the scale must be adjusted. Put the fence in a certain position and cut a test piece. Measure the length of the test piece. Loose the knob (A) under the scale and move the scale until it matches the length of the previously cut sample, see *Fig.49*


7. Operations

7.1 Safety Cautions

Machine operation may cause injury of operator. Before regular work we recommend you get the knowledge of operations to use scrap lumber to check settings. Read instructions carefully before you start to cutting. Always pay attention to safety cautions to avoid personal injury.

7.2 Electrical Operations (Fig.50)

Fig.50



- A1,A2 Start button for main blade**
—start the main motor.
- B1,B2,B3 Stop button**
—stop all motors
- C1,C2 Start button for Scoring blade**
—start the scoring motor
- D1,D2 Emergency stop button**
—disconnects power to all motors in the motor cabinet
- E Main power switch**
—connect or disconnect the all motor power.
- F Pilot lamp**
—when the power is supply, this Pilot lamp will be light;
- G, H, I, J Operation button for blade**
—up or down the blade and angle the blade ;

7.3 Digital Readout of fence angle Operation (Fig.51)

First time use this readout, you must calibrate it as next:

- a. Hold button **"ON/OFF"**, you can open this digital readout.
Hold button **"ON/OFF"** for more than 2 seconds, you can close this digital readout.
- b. Make sure the crosscut fence square to the main blade, press button **"ZERO"** for more than 2 seconds to zero clearing.

Calibration:

The calibration of the display unit have be done at the factory, it's in the working position; You must running check it, If necessary, calibrate it as next:

- a. Make sure the crosscut fence square to the main blade, press button **"ZERO"** for more than 2 seconds to zero clearing.
- b. Swung the fence to 45 degree, then cut a piece of workpiece to check the actual angle.
- c. Press **"ON/OFF"** & **"ZERO"** at the same time for more than 2 seconds, the last digit will twinkle, then press **"ZERO"** enter the calibration mode, digital display will decreased 1 degree.
- d. Press **"ZERO"** again, the digit will add 0.1, repeat this action, until the display value equal to the measured value.
- e. Press **"ON/OFF"** to save it and also exit the calibration mode, digital stops flashing,



Fig.51

7.4 Digital Readout of blade angle Operation

Model: IZ15E-001-4-01,0-0

7.4.1 Digital readout of angle blade



Fig.52




Fig.53

Note: Before you enter the environment of parameter setting, you must make sure the "⑥" shows "INC", if it shows "ABS", you must press "③" to change it.

7.4.1.1 Change the battery

1. Release the clamping screws and remove the housing with the display unit, *as Fig.53*;
2. Change the batteries, making sure the poling is correct, *as Fig.54*

7.4.2.2 Basic setting of the display unit

The basic setting of the display unit have be done at the factory, it's in the working position; You must running check it, If necessary, reenter the basic setting as next:(*see Fig.52*)

1. Cut a test block to make sure the blade is in the position of 90 degree, then check the displayed whether or not "0",
2. If not, Hold the "①" button for more than 4 seconds to enter the environment of parameter setting; Press the "①" button to select the parameter, Till the appearance of the parameter "P09"; Then press "②", "③" to input the number "0" and press "②" to save it;
3. Cut a test block to make sure the blade is in the position of 45 degree , Then check the displayed whether or not "45",
4. If not, Hold the "①" button for more than 4 seconds to enter the environment of parameter setting; Press the "①" button to select the Parameter, Till the appearance of the parameter "P08"; Then press "②", "③" to modify the number "0.0420" or other closer number , You can increase or decrease it, Then press "②" to save it;

modify the number example:

"0.0423" or "0.0421" or "0.0419" or "0.0418 and so on")

5. Hold the "①" button for more than 4 seconds, Till the screen flicker-free, Then check the displayed whether or not "45", If not, take the blade to the the position of 90 degree , press "①" and "②" at one time ,then take the blade to the the position of 45 degree, and repeat **Step 4 and Step 5**;

Attached Table :

(Digital readout Parameter setting)

Parameter	reference value	
	angle measurement	length measurement
P01	1	1
P02	3	0
P03	1	1
P05	000	000
P08	0.0420	1
P09	0	The basic setting by user



Fig.54

7.5 Blade Guard/Riving knife

The guard encloses the top of the blade to reduce the risk of accidental blade contact and contain flying chips or dust.

The guard is designed when workpiece is pushed toward the blade, keep in contacting with the workpiece during the cutting, then return to a resting position against the table when the cut is complete. When installed and properly maintained, the guard is an excellent device for reducing the risk of injury when operating the table saw.

To ensure that the guard works effectively, it **MUST** be installed and adjusted so that it moves up and down properly to accommodate workpiece and maintain cover the blade.

The spreader and riving knife are metal plates to prevent the freshly cut workpiece from pinching the backside of the blade and avoid kick-back. At the same time, these parts act as a barrier to shield hands from being pulled into the blade if a kick-back occurs and the operator is reaching behind the blade. (Reach behind the blade is a major safety risk and should not be done).

The blade guard **Must** be installed on the saw for all normal cuts. Sometimes the blade guard or its components hinder cutting very narrow workpieces or other specialized cuts. Because the blade guard is provided to decrease your risk of injury, it should not be used if it hinders a safe cut.

In general, the blade guard **Must** remain installed on the saw unless a specific operation requires its removal. If the blade guard is removed for specific operations, always immediately replace it after those operations are completed.

7.6 Crosscutting

1.The crosscut fence can be installed at two positions.

See *Fig.55*




Fig.55

Position 1: the operator presses the workpiece against the fence in the cutting direction.

Position 2: the operator pulls the workpiece along the fence against the cutting direction.

2.The crosscut fence can be swung $\pm 45^\circ$.

7.7 Rip Cutting

WARNING

When you use aluminum rip fence, Remove the crosscut fence/miter fence Use the sliding table lock lever to lock the sliding table.

When cutting width is less than 120mm, make sure that the material is fed with a push stick, and the stop fence is laid flat.

For cutting parallel, the rip fence is pushed up to the required dimension, the set dimension is read off from the edge of the aluminum rip fence.

The dimension can be adjusted to the individual tool thickness after release the knob under the scale.


For cutting short workpieces, the stop fence is moved forward until its rear end is in front of the saw blade.

The stop fence can be installed at two positions. See Fig.56

Position 1: Upright position of the stop fence for normal workpieces;

Position 2: Flat position of the stop fence;

The stop fence is moved into the flat position when cutting flat and narrow workpieces, this means there is more space for workpiece guidance and the fence can be moved closer to the saw blade, in particular, when the blade is tilted, without hitting the safety hood.



Upright position of the stop fence

Flat position of the stop fence

Fig.56

7.8 Clamping shoe

A clamping shoe for the irregular lumber. See **Fig.57**

Fit the clamping shoe on the sliding table, lay the workpiece with the hollow side down, and press underneath the shoe, push the workpiece forward by applying pressure with the ball of your right hand on the workpiece edge, place your hands with sufficient safety clearance from the tool.




Fig.57

8. Maintenance

WARNING

Always disconnect power to the machine before performing maintenance. Failure to do this may result in serious personal injury.

8.1 Cleaning

Cleaning this machine is relatively easy. Vacuum excess wood chips and sawdust, and wipe off the dust with a dry cloth, if any resin has built up, use a resin dissolving cleaner to remove it, treat all cast iron and unpainted steel with a non-staining lubricant after cleaning.

Once a Week:

- clean sliding table surface and grooves.
- clean the cast iron saw table.
- clean the roller guide ways for the sliding table.
- clean the extruded aluminum rip fence and sliding grooves.
- clean the round guide bar.
- clean the tilt segments.
- clean machine interior and environment.




Fig.58

8.2 Lubrication:

Saw shaft:

No lubrication of the saw shaft bearing is required;

Height adjustment / Tilt adjustment

As Fig.58

Remove the motor cover, set the tilt to 45 degree, and cutting height to 0mm

Lubricated next once a month:

- grunion (A) , two side;
- Two guide(B)




Fig.59




Fig. 60

8.3 Replacing belt.

Remove the motor cover, set the tilt to 45 degree, and cutting height to 0mm

1. Main motor belt. (Fig.59)

release four nuts (C), relax the main motor, rise the motor, you can loosen the belt, take out it and install new belt, thread nuts (C) to tighten the main motor to the bracket.

2. Scoring motor belt. (Fig.60)


release nut (F) and bolt (E), relax spring (D), rise the motor obey arrowhead, you can loosen the belt, take out it and install new belt, thread bolt (E) to tighten the spring and tighten nut (F).

9. Trouble shooting guide

PROBLEM	SOLUTION
<p>SAW WILL NOT START</p> <ol style="list-style-type: none"> 1. Saw not plugged in. 2. Fuse blown or circuit breaker tripped. 3. Cord damaged. 	<ol style="list-style-type: none"> 1. Plug in saw. 2. Replace fuse or reset circuit breaker. 3. Have cord replaced by a certified electrician.
<p>OVERLOAD KICKS OUT FREQUENTLY</p> <ol style="list-style-type: none"> 1. Extension cord too light or too long. 2. Feeding stock too fast. 3. Blade in poor condition (dull, warped, gummed). 4. Blade binding due to misaligned rip fence. 5. Blade binding due to warped wood. 6. Low house current. 	<ol style="list-style-type: none"> 1. Replace with adequate size cord 2. Feed stock more slowly. 3. Clean or replace blade. 4. Check and adjust the rip fence. See rip fence instructions. 5. Select another piece of wood. 6. Contact your electrical company.
<p>DOES NOT MAKE ACCURATE 45 AND 90 RIP CUTS</p> <ol style="list-style-type: none"> 1. Positive stop(s) not adjusted properly. 2. Tilt angle pointer not set properly. 	<ol style="list-style-type: none"> 1. Check blade with square and adjust positive stop. 2. Check blade with square and adjust pointer to zero.
<p>MATERIAL PINCHES BLADE WHEN RIPPING</p> <ol style="list-style-type: none"> 1. Rip fence not aligned with blade. 2. Warped wood. 	<ol style="list-style-type: none"> 1. Check and adjust rip fence. 2. Select another piece of wood.
<p>MATERIAL BINDS ON SPLITTER</p> <ol style="list-style-type: none"> 1. Splitter not aligned correctly with blade kerf. 	<ol style="list-style-type: none"> 1. Check and align splitter with blade kerf.
<p>SAW MAKES UNSATISFACTORY CUTS</p> <ol style="list-style-type: none"> 1. Dull blade. 2. Blade mounted backwards. 3. Gum or pitch on blade. 4. Incorrect blade for work being done. 5. Gum or pitch on table causing erratic feed. 	<ol style="list-style-type: none"> 1. Replace blade. 2. Turn blade around. 3. Remove blade and clean with turpentine and steel wool. 4. Change the blade. 5. Clean the table with turpentine and steel wool.
<p>BLADE DOES NOT COME UP TO SPEED</p> <ol style="list-style-type: none"> 1. Extension cord too light or too long. 2. Low house current. 3. Motor not wired for correct voltage. 	<ol style="list-style-type: none"> 1. Replace with adequate size extension cord. 2. Contact your electric company. 3. Refer to motor and /or nameplate.
<p>MACHINE VIBRATES EXCESSIVELY</p> <ol style="list-style-type: none"> 1. Table not mounted securely to cabinet stand. 2. Stand is on uneven floor. 3. Damaged saw blade. 4. Bad V-belt(s). 5. V-belts not tensioned properly. 6. Bent pulley. 7. Improper motor mounting. 8. Loose hardware. 	<ol style="list-style-type: none"> 1. Tighten all mounting hardware. 2. Reposition on flat level surface. 3. Replace blade. 4. Replace V-belt(s). 5. Adjust V-belt tension. 6. Replace pulley. 7. Check and adjust motor mounting. 8. Tighten all nuts, bolts and set screws.
<p>BLADE DOES NOT RAISE OR TILT FREELY</p> <ol style="list-style-type: none"> 1. Sawdust or dirt in raising or tilting mechanisms. 	<ol style="list-style-type: none"> 1. Brush or blow out loose dust or dirt.


10. Parts List

Main Base--NANO



REF	DESCRIPTION	REF	DESCRIPTION
1	Cabinet	16	Hinge
2	Motor cover	17	Cap screw M5X12
3	Switch box back cover	18	/
4	Switch box	19	Screw M4X8
5	Switch box cover	20	Adjustment nut
6	/	21	Rivet nut M6X18
7	Flat head screw M4X12	22	Flat Washer 6
8	Flat washer 4	23	Spring Washer 6
9	Button	24	Cap screw M6x20
10	Button	25	Set screw M12X40
11	Button	26	Nut M12
12	Light	27	Flat washer 5
13	Start button	28	Spring washer 5
14	Stop button	29	Cap screw M5X16
15	Quick stop button	30	Foot


Main Table



REF	DESCRIPTION
1	Main table
2	Hex Bolt M10X70
3	Spring Washer 10
4	Big Washer 10
5	Aluminium Block
6	Aluminium Block
7	Button Head Screw 6x4

REF	DESCRIPTION
8	Spring Washer 6
9	Aluminium Bar
10	Button Head Screw 6x25
11	Aluminium Bar
12	Aluminium Bar
13	Washer with cone face D10
14	Washer with ball face D10

Side Table




REF DESCRIPTION

1	Side table
2	Flat HD screw M6X16
3	Bracket
4	Bracket
5	Bracket
6	Leg
7	Foot

REF DESCRIPTION

8	Flat washer 8
9	Spring washer 8
10	Cap screw M8X25
11	HEX bolt M8X30
12	Flat washer 6
13	Spring washer 6
14	Nut M6

Rear Table




REF DESCRIPTION

1	Rear table
2	Flat HD screw M6X16
3	Bracket
4	Bracket
5	HEX bolt M8X30
6	Leg
7	Foot

REF DESCRIPTION


8	Flat washer 8
9	Spring washer 8
10	Cap screw M8X25
11	Flat washer 6
12	Spring washer 6
13	Nut M6

Sliding Table for N-1600




REF	DESCRIPTION	REF	DESCRIPTION
1	Sliding Table 1600	16	Spring washer 5
2	Handle	17	Cap screw M5X12
3	Draw handle	18	Under cover
4	Flat washer 6	19	Restrain PG 9
5	Spring washer 6	20	Bracket
6	Flat HD screw M6X16	21	Cover
7	Flat washer 10	22	Bracket
8	Spring washer 10	23	Flat HD screw M5X12
9	Cap screw M10X16	24	Towline
10	Cap screw M10X40	25	Flat HD screw M5X12
11	Block	26	Flat HD screw M4X8
12	Stop block	27	Start button
13	Cap screw M6X16	28	Stop button
14	Positioning knob		
15	Flat washer 5		

Sliding Table for N-2500



REF	DESCRIPTION	REF	DESCRIPTION
1	Sliding Table 2500	17	Leg
2	Handle	18	Flat washer 5
3	Draw handle	19	Spring washer 5
4	Flat washer 6	20	Cap screw M5X12
5	Spring washer 6	21	Under cover
6	Flat HD screw M6X16	22	Restrain PG 9
7	Flat washer 10	23	Bracket
8	Spring washer 10	24	Cover
9	Cap screw M10X16	25	Bracket
10	Cap screw M10X40	26	Flat HD screw M5X12
11	Block	27	Towline
12	Stop block	28	Flat HD screw M5X12
13	Cap screw M6X16	29	Flat HD screw M4X8
14	Positioning knob	30	Start button
15	Cap screw M10X25	31	Stop button
16	Adjust foot		

Tilting assembly



REF DESCRIPTION

- 1 Front bracket
- 2 Rear bracket
- 3 Spring washer 10
- 4 Cap screw M10X40
- 5 Flat washer 10
- 6 Adjust nut
- 7 Nut M10
- 8 Nylon washer
- 9 Flat washer 8
- 10 Spring washer 8
- 11 Cap screw M8X30
- 12 Front supporting bracket
- 13 Rear supporting bracket
- 14 Connecting rod
- 15 Connecting rod


REF DESCRIPTION

- 16 HEX head bolt M8X30
- 17 Adjust knob
- 18 Handle bracket
- 19 Flat washer 6
- 20 Spring washer 6
- 21 Cap screw M6X30
- 22 HEX head bolt M8X40
- 23 Nut M8
- 24 HEX head bolt M8X65
- 25 Guide pillar
- 26 Guide pillar
- 27 HEX head bolt M8X35
- 28 Bearing JZF25-25
- 29 Big washer 5
- 30 Spring washer 5

REF DESCRIPTION


- 31 Cap screw M5X16
- 32 Lifting bracket
- 33 Air spring
- 34 Air spring
- 35 Dust box
- 36 Dust box cover
- 37 Cap screw M6X20
- 38 Cap screw M6x12
- 39 Dust plate
- 40 Shoulder screw 8X10
- 41 Air spring bracket
- 42 Angle positioning block
- 43 Dust outlet

Main arbor assembly



REF	DESCRIPTION	REF	DESCRIPTION
1	Lock Nut	17	Spring washer 5
2	Flange	18	Flange Ring
3	Set Screw M8x25	19	Flat washer 5
4	Adjust Plate	20	Cap screw M5X16
5	Main Arbor	21	Collar
6	Key 6x32	22	Pulley
7	Bearing 6006-2RS	23	Washer
8	Spring Ring	24	Bolt
9	Bearing 6005-2RS	25	Cap Screw M8X16
10	Button HD screw M6X16	26	Plate
11	Spring washer 6	27	Adjust Plate
12	Blade Guard Bracket	28	Set Screw M6x16
13	Main Arbor Bracket	29	Slide Block
14	Flat washer 8	30	Square Nut
15	Spring washer 8	31	Flat HD screw M10X25
16	Cap Screw M8X45		

Scoring arbor assembly




REF DESCRIPTION

1	Lock nut
2	Flange
3	Adjust plate
4	Scoring arbor
5	key 5x25
6	Bearing 6005-2RS
7	Spring ring
8	Scoring sleeve
9	Bearing 6203-2RS
10	Collar
11	Flange ring
12	Pulley
13	Nut
14	Flat washer 6
15	Spring washer 6
16	Button HD screw M6X16

REF DESCRIPTION

17	Adjust plate
18	Flat washer 8
19	Spring washer 8
20	Cap screw M8X16
21	Lock nut M12
22	Washer
23	Bearing
24	Adjust shaft
25	Block
26	Set screw M6X16
27	Cap screw M6X40
28	Adjust nut
29	Nylon block
30	Set screw M10X12
31	Opening ring 12


Main motor assembly



REF	DESCRIPTION
1	Motor
2	Beltt
3	Pulley
4	Set screw M6X12
5	Flat washer 10

REF	DESCRIPTION
6	Spring washer 10
7	Nut M10
8	HEX head bolt M10X50
9	Resrrain M30-2
10	Cable

Scoring motor assembly




REF	DESCRIPTION
1	Motor
2	pulley
3	Big Flat Washer 6
4	Flat Washer 6
5	Spring Washer 6
6	Button Head Screw M6*16
7	Hex Bolt M8x30
8	Motor Suppor

REF	DESCRIPTION
9	Falt wsher 8
10	Spring washer 8
11	Nut M8
12	Nylon Sleeve
13	Big washer 8
14	Cap Screw M8x16
15	Supporting shaft
16	Set Screw M8x16


REF	DESCRIPTION
17	Spring
18	Hex Bolt M10x70
19	Cap Screw M6x12
20	Strap PJ270
21	Nut M10
22	Nylon block
23	Cable

Rip fence body assembly (Rod guide)




REF	DESCRIPTION	REF	DESCRIPTION	REF	DESCRIPTION
1	Fence	23	Set screw M8X8	45	Guide rod
2	Spring ring 12	24	Cam	46	Positioning cover
3	Roller	25	Key 4X12	47	Cap screw M12X25
4	Shaft	26	Locking nut M8	48	Cap screw M8X10
5	Flat washer 10	27	Nut M6	49	Bolt
6	Spring washer 10	28	HEX bolt M6X20	50	Nut M16
7	Nut M10	29	Locking cam	51	Spring washer 16
8	Fence body	30	Set screw M8X12	52	Flat washer 16
9	Eccentric wheel	31	Spring ring 16	53	Spring washer 6
10	Cap screw M6X16	32	Locking shaft	54	Flat washer 6
11	Locking bar	33	Set screw M6X16	55	Ruler block
12	Locking bar rod	34	Lock Block	56	Ruler
13	Spring	35	/	57	/
14	Nut M8	36	Flat HD screw M5X12	58	Screw M2X10
15	Spring washer 8	37	Flat washer 5	59	Adjust nut
16	Flat washer 8	38	/	60	Adjust knob block
17	Connecting plate	39	/	61	Locking knob
18	Knob	40	Spring washer 5	62	Adjust knob
19	Knob shaft	41	/	63	Washer
20	Knob block	42	/	64	Lock nut M10
21	Locking shaft	43	/	65	Nylon screw M8X12
22	Bearing	44	Calibration window		

Crosscut table assembly




REF	DESCRIPTION	REF	DESCRIPTION	REF	DESCRIPTION
01	Bearing shaft	22	Pin	43	Lock washer
02	Nut M20	23	Work bench	44	Cap screw M8X60
03	Block	24	Cap screw M5X20	45	Flat washer 8
04	Bearing shaft	25	Limit block	46	Spring washer 8
05	Set screw M8X40	26	/	47	Spring
06	Nut M8	27	Lock block	48	Washer
07	Spring washer 6	28	Spring	49	Block
08	Cap screw M6X25	29	Bracket	50	O-Ring
09	Nut M20	30	Plate	51	Set screw M6X8
10	Slide bar	31	Set screw M6X12	52	Collar
11	Supporting bar	32	Limit block	53	Spring washer 10
12	Swing arm	33	Nut M12	54	Cap screw M10X25
13	Spring ring 15	34	Flat washer 12	55	Knob
14	Roller	35	Roll sleeve	56	Screw M6X12
15	Roller shaft	36	Supporting bar	57	Block
16	Flat washer 8	37	Film	58	Lock knob
17	Spring washer 8	38	Lock knob	59	Spring
18	Flat HD screw M8X16	39	Set screw M5X8	60	Lock block
19	Nylon block	40	Lock shaft	61	Lock knob
20	Magnet	41	Nut M10	62	Lock block
21	Screw M5X25	42	Set screw M10X40	63	Cover

Crosscut Fence assembly




REF#	DESCRIPTION	REF#	DESCRIPTION	REF#	DESCRIPTION
801	Crosscut Fence	822	Extend Fence	843	Board
802	Locking block	823	Below plate	844	Scale
803	Connection block	824	Flat washer 6	845	windows
804	Transfer coating of splitting	825	Cap screw M6X16	846	Set screw M6X12
805	Connecting bar	826	Cover	847	Nut 6
806	Rivet net M5X18	827	Cap screw M4X8	848	Set screw M6X12
807	Cap screw M5X65	828	Cap screw M8X20	849	Scale
808	Konb	829	Spring washer 8	850	Bearing 6002
809	Locking block	830	T-oriented block	851	Rotating block
810	Handle	831	Spring	852	Cap screw M3X10
811	T-block	832	Impact Block	853	Flat washer 3
812	Limit block	833	Flat washer 10	854	Connecting block
813	Spring washer 6	834	Handle	855	Spring 4
814	Cap screw M6X30	835	Flat Head Screw M4X12	856	Flat wahser 4
815	Nylon Block	836	windows	857	Cap screw M4X10
816	Lock Base	837	Locking nut M8	858	Set screw M4X4
817	Handle	838	Fixed block	859	Cap screw M5X8
818	Flat washer 5	839	Set screw M5X30	860	Flat Head Screw M6X8
819	Cap screw M5X16	840	Pin	861	Angle display
820	Core Ruler	841	Washer	862	Circlip
821	Rivet net M8X18	842	Nylon screw	863	Circlip

Blade guard assembly




REF	DESCRIPTION	
01	Riving Knife	1
02	Splitter	1
03	Blade Guard (left)	1
04	Blade Guard (right)	1
05	Spring Washer 6	3
06	Cap Screw M6X25	3
07	Cap Screw M10X25	1
08	Spring Washer 10	1

Electrical components for tilting assembly



REF	DESCRIPTION	REF	DESCRIPTION	REF	DESCRIPTION
1	Cap screw M4X35	15	Washer	29	Cap screw M6X35
2	Switch	16	Bearing	30	Bracket
3	Switch bracket	17	Shoulder screw 10-16	31	Spring washer 4
4	Flat washer 5	18	Nut M10	32	Flat washer 4
5	Spring washer 5	19	Electric putter	33	Electric putter driver
6	Cap screw M5X20	20	Electric putter	34	Contact bracket
7	Cp screw M616	21	Lock nut M16	35	Nut M6
8	Spring washer 6	22	Flat washer 8	36	Magnescale bracket
9	Flat washer 6	23	Bearing	37	Bracket
10	Switch contact	24	Bracket	38	Cap screw M3X10
11	Cap screw M4X14	25	Shoulder screw 8-55	39	Gland
12	Lock nut M4	26	Hex bolt M6X20	40	Magnescale
13	Safety limit switch	27	Switch bracket	41	Display
14	/	28	Bracket		

Electrical Box Assembly



REF	DESCRIPTION
1	Electrical box
2	Combination plug
3	/
4	12-pin connector
5	Network cord
6	3-pin connector
7	Restrain PG11
8	Restrain PG11
9	Restrain PG11
10	Restrain PG11
11	Restrain PG16
12	Cable (4x2.5)
13	Cable (4x3.5)

REF	DESCRIPTION
14	Cable (2x0.5)
15	3-pin connector
16	Network cord
17	Network cord
18	Isolating switch
19	Relay
20	Contacteur
21	Contacteur
22	Contacteur
23	Circuit Breaker
24	Transformer
25	Relay
26	Relay

REF	DESCRIPTION
27	Stop circuit board
28	Terminal
29	Quick stop button
30	Light
31	Stop button
51	Connector
52	Connector
53	Relay
60	Restrain PG11
61	Cable